

North Florida Communications

www.northfloridacommunications.com www.ournewphone.com

LG IPECS Staion Name Programming

You can designate a "name" for your station. This name will appear on your display, as well as the display of any other station in your system that you call or that calls you.

- 1) Select "Menu".
- 2) Press "1" for Phone Setting
- 3) Press "1" for Station Name Programming
- 4) Enter the Station Name
- 5) Press "HOLD/SAVE" to save the entry.

To input characters,

- 1) To input the first character of a button, press the button 1 time (ex. for 'a', press 2 button once).
- 2) To input the second character of a button, press the button 2 times (ex. for 'b', press the 2 button twice).
- 3) To input the third character of a button, press the button 3 times (ex. for 'c', press the 2 button three times).
- 4) Press the second Soft button to select ABC> or abc> mode.

To delete characters,

1) press DND button.