



North Florida Communications

www.northfloridacommunications.com

www.ournewphone.com

LG ipLDK-60 Changing Ring Type

- 1) Select "Menu". This is the up-arrow key on the navigation wheel at the bottom of the phone.
- 2) Press "1" for "Basic Program"
- 3) Press "2" for "Ring Program"
- 4) Press "1" for Intercom Ring (Inside Callers) or "2" for CO Ring (Outside Callers)
- 5) Press the "Next" soft-key to scroll through the different ring tones.
- 6) Press the "OK" soft-key to save the ring tone.